






























## Feature operation

<b>Hold</b>	<b>Off Hold</b>	
Place a call on hold	 (Hold)	Take a call off hold  (Line)
<b>Transfer</b>	Trans	 Trans
<b>Conference</b>	Conf	 Conf
<b>Last Number Redial</b>		 (Line)
<b>Ring Again</b>	Activate RngAgn	
When notified		 RngAgn
Deactivate	 RngAgn	
<b>Call Forward</b>	Activate Fwd  Fwd	
Deactivate	 Fwd	
Reinstate	Fwd	 Fwd
<b>Call Pickup</b>		Pickup
<b>Message</b>		 (Messages)

## Icon legend

Icon	Action
( )	Indicates the text version of the key cap instead of the icon. For example, (Hold) instead of  .
	A lock on the display indicates an encrypted call.
 (Hold)	Press the Hold key to place a call on hold.
	Lift the handset
	Replace the handset
	Dial a number using the dialpad.
 (Line)	Press the Line key
 (Services)	Press the Services key to view options or exit.
 (Messages)	Press the Message key to access your voice mailbox
	Press the Navigation keys to scroll through the menus.
 Fwd	The  flashes when a feature is being programmed. The  is steady when the feature is active.

## Services and telephone options menu

<b>Services Menu</b>
 (Services)  Select

The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **Branch Office** menus.

**Note:** The **Password Admin**, **Virtual Office**, and **Branch Office** menus may not be available on your IP Phone 2001. Consult your system administrator.

### Telephone Options

#### Volume adjustment

Ringer	Select			Select Cancel	
Handset Listen	Select			Select Cancel	
Handsfree Listen	Select			Select Cancel	
Buzzer	Select			Select Cancel	

#### Contrast adjustment

		Select			Select Cancel	
---	---	--------	---	---	---------------	---

#### Language

		Select			Select Cancel	
---	---	--------	---	---	---------------	---

#### Date/ Time

		Select			Select Cancel	
---	---	--------	---	---	---------------	---




#### Local dialpad tone

		Select			Select Cancel	
---	---	--------	---	---	---------------	---




#### Ring type

		Select			Select Play Cancel	
---	---	--------	---	---	--------------------	---

#### Call timer

		Select	Turn on or off	Select Cancel	
---	---	--------	----------------	---------------	---

#### Live dialpad

		Select	Turn on or off	Select Cancel	
---	---	--------	----------------	---------------	---

For additional information about your IP Phone, see the *Nortel IP Phone 2001 User Guide* (NN43115-102).

## Nortel IP Phone 2001



# NORTEL

www.nortel.com

## IP Phone 2001

For Nortel Communication Server 1000

### Quick Reference Card



To provide feedback or report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

Date: May 2007  
Document Release: Standard 01.01  
Document Number: NN43115-100  
Copyright © 2007 Nortel Networks  
All rights reserved.

\* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.